




Professional Photographic Equipment

INSTRUCTIONS

R-4X/5X Series Tripod



Guangdong SIRUI Optical Co., Ltd.

Address: The Third Industrial District, Wujiahuatan Town, Zhongshan City, Guangdong, China
Tel: 0086-760-88927373 Fax: 0086-760-88207062 Service Hotline: 0086-400-8302299
E-mail: info@sirui-photo.com http://www.sirui.com P.C: 529458



R-4X/5X Series Tripod Data Chart

Section	Max Dia mm/inch	Min Dia mm/inch	Min Hgt mm/inch	Max Hgt mm/inch	Max Hext mm/inch	Retracted H mm/inch	Folded H mm/inch	Monopod Max.H mm/inch	Monopod Min.H mm/inch	Weight kg/lb	Load kg/lb
R-4213X	3	36/1.4	28/1.1	105/4.1	1500/59.1	660/26.0	1500/59.1	1500/59.1	1500/59.1	2.2/4.9	25/55.1
R-4214X	4	36/1.4	24/0.9	90/3.5	1500/59.1	550/21.7	1500/59.1	1500/59.1	1500/59.1	2.2/4.9	25/55.1
R-5214X	4	40/1.6	28/1.1	90/3.5	1600/63.0	580/22.8	1600/63.0	1600/63.0	1600/63.0	2.5/5.5	30/66.1
R-5214XL	4	40/1.6	28/1.1	100/3.9	2000/78.7	690/27.2	2000/78.7	2000/78.7	2000/78.7	2.8/6.2	30/66.1

图纸名称：思锐R-4X/5X系列说明书

物料编号：PR32-1

制图：彭少章

审核：

批准：

WARRANTY CARD INFORMATION

Dear SIRUI Customer,
Thank you for your purchase of SIRUI Professional Products!
SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty Begins on the original date of purchase on your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
Tripods / Monopods / Accessories	6 years
Humidity Control Cabinet (Cabinet)	3 years

Model: _____ Date: _____
Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI 6 (six) Year Limited Warranty (3 Year Warranty for Electronic Parts). This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributors option, or defective parts, free of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or inconveniences or consequential damages to equipment, or by breach of any expressed or implied warranties.

Limitations:
Warranty is not transferable.
This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:
1. If the equipment has been serviced by other than an authorized SIRUI Service Center.
2. Service center equipment is due to modification (including but not limited to the removal of ballhead clamps), overloading, mishandling, abuse, accident, sand, corrosion, water damage, or other following operating instructions.
3. No valid proof of purchase is provided.
4. Damage caused by acts of nature (including, but not limited to fires, floods or earthquakes).
*Series Waterproof/Dustproof models - Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.

Warranty Address and Contact Information:
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.
The Third Industrial District, Wujiahuatan Town, Zhongshan City, Guangdong.
Tel: 0086-760-88927373 Fax: 0086-760-88207062
http://www.sirui.com E-mail: info@sirui-photo.com
Service Hotline: 0086-400 830 2299

2. SIRUI USA, LLC
Add: 29 Commerce Court Verona, NJ 07044
www.sirui.com
Service: Toll Free 866-373-0829 E-mail: info@sirui.com
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE:
For full details on USA Warranty Terms and Limitations:
www.sirui.com/warranty.html
To register products: www.sirui.com/product-registration.html

3. Focus Nordic AB
For technical support, service or repairs, please contact:
Sweden: info@focusnordic.se www.focusnordic.se
Norway: info@focusnordic.no www.focusnordic.no
Denmark: info@focusnordic.dk www.focusnordic.dk
Finland: info@focusnordic.fi www.focusnordic.fi
Iceland: info@focusnordic.is www.focusnordic.is
Latvia: info@focusnordic.lv www.focusnordic.lv
Estonia: info@focusnordic.ee www.focusnordic.ee
Lithuania: info@focusnordic.lt www.focusnordic.lt
Poland: info@focusnordic.pl www.focusnordic.pl

4. SIRUI Europe GmbH (European Service Center)
Add: Fiederstr.21, 74039 Berlin, Germany
Phone: +49 221 94 99 54-50 E-mail: info@sirui.de
(Please contact the seller or your local distributor for warranty issues.)


5. TSE Imaging BV
Add: Aarweg 135, 1362AD Almere, The Netherlands
Tel: +31 361 531 038 8450348 E-mail: service@tse-imaging.nl
(Exclusive Distributor for Netherlands, Belgium, Luxembourg)
www.sirui-photo.nl

6. 다국언터프라이즈
한국 총판: 기술지원 및 고객서비스국
서울특별시 중구 남대문로10, 1층
Tel: 02-752-3304 Fax: 02-74-9903
www.sirui.co.kr loweprokr@gmail.com


Know your tripod



Included accessories
75mm Bowl Adapter
Steel spike



R-4X/5X Three Position Leg Angle Adjustment



1. Knowing your R-4X/5X series tripod (shown in fig 1)

The R-4X/5X series tripods have 3 different leg angle positions 24°, 54° and 84°, for shooting on uneven terrain.

3. R-4X/5X Pull-out Leg Angle Lock with Automatic Locking Mechanism (shown in fig 2)

Pull out the Leg Angle Lock and move the leg to a horizontal position, until you will hear a "click". The lock will automatically return to its original position.

4. Hook can be used as an Allen key (shown in fig 3)

Remove the hook from the bottom of the Mounting Plate, the hook can be used as an Allen key to tighten/loosen the 3 Mounting Plate Locking screws and tighten/loosen the Head Locking screw.

5. R-4X/5X Platform and adapter bowl exchange (shown in fig 8)

Remove the hook from the bottom of Mounting Plate, then use the Allen key to loosen the 3 Mounting Plate Locking screws on the Mounting Platform. Remove the Mounting Plate and replace with the 75mm Bowl Adapter. Use the hook (Allen key) to lock the 3 Mounting Plate Locking screws (when you replace the Mounting Plate, align the Head Locking screw to one of the Mounting Plate Locking screws, so there will be enough space to reach the Head Locking screw on the bottom of the Mounting Plate). Video heads can be attached to the 3/8" screw, the Head Locking screw secures the video head to the leveling head; the 75mm leveling head can be placed in the 75mm Bowl Adapter.

6. R-4X/5X Leg Extension and closing (shown in fig 5)

As shows in fig. 5, twist the legs 1/4 turn in a clockwise direction, then extend the leg to your desired length, and lock the legs from biggest to smallest, when all the legs are closed, lock the leg from small knob to big knob.

7. Rubber foot and steel spike exchange (shown in fig 6)


8. R-4X/5X Assembling the leg and shim (shown in fig 4)

Place the two shims into the corresponding holes in the leg. Then, align the gap between the shims of the lower leg with the arrow on the upper leg and slide the lower leg up until the shim is not visible. Screw the Rubber Leg Lock onto the upper leg.

Leg Angle Adjustment




The hook is also an Allen key to lock/unlock the Mounting Plate Locking screw.



R-4X/5X Exchanging the Mounting Plate and 75mm Bowl Adapter

Use the Allen key to loosen the three Mounting Plate Locking screws on the Mounting Platform, exchange the Mounting Plate or 75mm Bowl Adapter, then re-tighten the three Mounting Plate Locking screws.



Attention:

Do not exceed the recommended load limit of the head and/or tripod. (Please refer to product specifications.)

Please make sure that the locks are securely tightened when in use.

This product should not be used in environments that exceed the following conditions (-40 ~ +100°C/-40 ~ +212°F). And, when used in damp, dirty or dusty environments, please clean and dry thoroughly after use to assure proper functioning in the future. It is not recommended to expose this product to saltwater. If exposed, please clean with mild soap and warm water and towel dry.

Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.

Please do not leave the equipment alone in a public place, which can be an inconvenience or hazard to others.

To protect your camera gear, please remove it from the tripod/head when transporting from place to place.

Please use a soft towel with warm water and mild soap to clean the locking system and gliding parts when necessary. Towel dry before storing the tripod.

Under most situations, there is no need to lubricate any parts of this product. The addition of most lubricants will gum up the mechanisms and reduce their normal gliding characteristics. Please call or email us if you have any questions or special needs.

Please keep this product away from all electrical power sources.

CAUTION

Please remove the camera from the tripod when changing the position of the tripod. Do not place the tripod with camera attached over your shoulder or carry the tripod horizontally by the legs. Strong shaking may cause damage of the screw in the mounting plate and/or the camera. Please extend the legs from the biggest tube to smallest tube, close the legs from the smallest tube to biggest tube, to avoid leg joint bushing damage.

Specifications are subject to change without notice.