

图纸名称: T-S系列说明书
物料编号: PT206
材质: 100g双胶/CMYK四色印刷
展开尺寸: 720x210mm
成型尺寸: 72x105mm

T-S系列说明书正面(英文版):




Instructions
T-S Series Tripod

QR CODE


GUANGDONG SIRUI OPTICAL CO.,LTD.
Address: The Third Industrial District, Wuyangshan Town, Zhongshan City, Guangdong, China
Tel: 0086-750-8897373 Fax: 0086-750-8821762
E-mail: info@sirui.com Website: www.sirui.com

1. Know the Product




Mounting Platform
Center Column
Spider
Bubble Level
1/4 Screw accessory attachment point
Leg-Lock Release Button
Foam Grip
Tripod Leg
Hook
Leg Locking Knob
Rubber Foot

2. Leg Angle Adjustments and Folding




(1) Push the tripod leg inward toward the Center Column to enable adjustment.
(2) Press the lower part of the leg angle button, the upper part will open to allow leg angle adjustments.
(3) Lift the leg up to about 90 degrees until the button clicks into place automatically, then adjust the leg to the desired angle. (Or lift the leg up to the desired angle directly, press the upper part of the button to lock in the angle desired.)
(4) Adjust the leg to a desired angle.

3. Extend or Retract the Tripod Legs




Tighten the Leg Locking Knobs from small to large after the Leg Sections are extended.
Tighten the Leg Locking Knobs from large to small after the Leg Sections are retracted.

4. Use of the Dual-Stage Center Column




Extend or retract the Center Column
Loosen and remove the Hook to use as an Allen Key for reverse shooting
Reverse the Center Column for low angle shooting

5. Convert the Detachable Leg into a Monopod




Turn clockwise to loosen the Monopod Leg
Turn counter-clockwise to tighten the Monopod Leg
(1) Detachable Leg
(2) Attach the Mounting Plate onto the detachable leg to extend the Monopod height
(3) The Center Column can be attached to the detachable leg to extend the Monopod height

6. Change the Rubber Feet to Spiked Feet



Loosen and remove the Rubber Feet
Change to Spike

7. Use of Mounting Screw, Set Screw and 1/4 screw accessory mounting hole.



Set Screws for fixing the Ball Head
Convert the Mounting Screw from 3/8" to 1/4"
1/4" Screw Hole for connecting photography accessories with 1/4" screw.

WARRANTY INFORMATION

Dear SIRUI Customer, Thank you for your purchase of SIRUI Professional Products! Please see the contact information below for product registration, information and service for the region the product was purchased in.

Product	Warranty Length
Tripods, Monopods, Accessories	3 years
Humidity Control Cabinet (Calibret)	6 years
Humidity Control Cabinet (Elextronics)	3 years

Model: _____ Date: _____
Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI 6 (Six) Year Limited Warranty (3 Year Warranty for Electronic Parts)

This product should be used in environments that exceed the following conditions: 40° ~ 100°C (40° ~ 212°F) and, when used in damp, dirty or salty environments, please clean and dry thoroughly after use, to assure proper functioning in the future. It is not recommended to expose this product to saltwater. If exposed, please clean with mild soap and warm water and towel dry.

Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.

Please do not leave the equipment alone in a public place, which can be an inconvenience or hazard to others.

To protect your camera gear, please remove it from the tripod ball head when transporting from place to place.

Use a soft towel with warm water and mild soap to clean the locking system and girding parts when necessary. Towel dry before storing the tripod.

Under normal situations, there is no need to lubricate any parts of this product. If most lubricants will gum up the mechanisms and reduce their normal girding characteristics. Please call or email us if you have any questions or need parts.

Please keep this product away from electrical power sources.

CAUTION
Please remove the camera from the tripod before carrying the tripod. Do not use the tripod as a step ladder. Do not use the tripod as a support for heavy equipment. Do not use the tripod as a support for heavy equipment. Do not use the tripod as a support for heavy equipment. Do not use the tripod as a support for heavy equipment.

Warranty Address and Contact Information:
Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.

Guangdong SIRUI Optical Co., Ltd.
Tel: 0086-750-8897373 Fax: 0086-750-8821762
E-mail: info@sirui.com Website: www.sirui.com
Service Hotline: 0086-400-830-2299

SIRUI USA, LLC
Address: 28 Commerce Court Verona, NJ 07044
Service: 531 Fax: 908-273-6828 E-mail: info@us.sirui.com
For PRO PRODUCTS PURCHASED IN THE U.S.A. & U.S. SEE: www.us.sirui.com For USA Warranty Terms and Limitations.

SIRUI EUROPE GMBH (European Service Center)
Address: Fiedlerstr. 2, 40505 Berlin, Germany
Phone: +49 30 21 818 54-0 E-mail: info@eu.sirui.com
(Please contact the seller or your local distributor for warranty issues.)

SIRUI ARGENTINA B.V.
Address: Argweg 135, 1162AD Almere, The Netherlands
Phone: +31 (0)20 8402049 E-mail: service@arg.sirui.com
(Eurasia Distributor for Netherlands, Belgium, Luxembourg)

T-S系列说明书背面(中文版):




使用说明
T-S系列三脚架

QR CODE


广东思锐光学股份有限公司
地址: 广东省中山市五桂山三工业区
电话: 0750-8897373 传真: 0750-8821762 邮编: 528458
E-mail: info@sirui.com 网站: www.sirui.com

1. 认识产品




转接螺丝
转接平台
中轴
本体
方向水平球
按钮
护手套
支撑脚
脚管紧固按钮
脚钉

2. 角度调节及三脚架折叠




1) 首先拿起脚架, 前中轴方向收合一下支撑脚。
2) 按下按钮的下部, 按钮上部会保持打开的状态。
3) 再把脚管往上扳动的90度, 直到按钮会自动回位后, 即可调整到所需的角度。(或者直接将脚管往上扳到所需的角度, 由三脚架的方向按下按钮的上部, 按钮会嵌入所需的角度卡位锁定。)
4) 然后把脚管往下打到所需的角度卡位。

3. 脚管的伸缩




脚管打开后分别从大到小的顺序拧紧各个紧固按钮。
脚管收缩后分别从小到大的顺序拧紧各个紧固按钮。

4. 中轴的使用




中轴升降调节
拧松挂钩, 可选六角扳手工具使用, 调节中轴方向实现侧置拍摄。
更换中轴, 可转换成低轴模式。

5. 可拆卸可转换成独脚架




3) 拆卸脚管
2) 安装转接平台及转接螺丝转换成独脚架
1) 可与中轴连接转换成独脚架

6. 包胶脚钉换成钢钉模式



拧松拆卸脚钉
转换成钢钉模式

7. 转接螺丝、紧固螺丝以及1/4螺纹接口的使用



紧固螺丝用于固定云台
转接螺丝上的3/8螺丝使用方向可转换成1/4螺丝使用
1/4螺纹接口用于连接摄影附件

保修卡

尊敬的顾客: 感谢您购买思锐的产品。在正常使用过程中, 如因器材本身的材料及工出厂质量问题, 思锐将提供免费保修服务。如有需要保修服务, 请提供本保修卡和购买凭证(收据或发票, 须有商家盖章), 思锐公司售后服务热线: 400-830-2299

产品名称	保修期限
三脚架	6年
防潮箱本体	3年
电子部分	3年

产品型号: _____ 购买日期: _____
商家名称: _____ 商家电话: _____
商家地址: _____
保修地点: _____
保修电话: _____

保修范围:
1. 保修产品: 享受6年免费保修(电子部分为3年), 保修时间从购买之日起算;
2. 所保修产品, 必须是正式授权的经销商或电子商务购买; 翻新产品不在保修范围内; 请先到经销商处服务, 确认后, 再送公司承担来回运费。一般性故障可在7个工作日内完成维修并寄回;
3. 以下情况不在保修范围:
① 超过保修期限的;
② 未按使用说明书正确使用造成损坏的;
③ 在未授权经销商或维修中心维修过的;
④ 由于不当操作、意外时间、自然灾害导致的故障或损坏。
* 保修卡只限在中国大陆使用

维修登记表

用户姓名	用户电话	用户地址	故障描述	维修人员姓名	维修时间

T-S系列三脚架参数

型号	重量	最大承重	最大高度	最小高度	脚管长度	脚钉长度
T-20000K	4.2	15.0	1510	510	480	110
T-20000K	4.2	15.0	1440	510	480	110
T-20000K	4.2	15.0	1370	510	480	110
T-20000K	4.2	15.0	1300	510	480	110
T-20000K	4.2	15.0	1230	510	480	110
T-20000K	4.2	15.0	1160	510	480	110
T-20000K	4.2	15.0	1090	510	480	110
T-20000K	4.2	15.0	1020	510	480	110
T-20000K	4.2	15.0	950	510	480	110
T-20000K	4.2	15.0	880	510	480	110
T-20000K	4.2	15.0	810	510	480	110
T-20000K	4.2	15.0	740	510	480	110
T-20000K	4.2	15.0	670	510	480	110
T-20000K	4.2	15.0	600	510	480	110
T-20000K	4.2	15.0	530	510	480	110
T-20000K	4.2	15.0	460	510	480	110
T-20000K	4.2	15.0	390	510	480	110
T-20000K	4.2	15.0	320	510	480	110
T-20000K	4.2	15.0	250	510	480	110
T-20000K	4.2	15.0	180	510	480	110
T-20000K	4.2	15.0	110	510	480	110

说明书折叠方法:

